

# **BGC PLASTERBOARD COMPOUND TECHNICAL SHEET**







## **BGC PLASTERBOARD COMPOUND TECHNICAL SHEET**

### **Application**

### **Joint Finishing**

When sanding Exterior Topping use 180 grit sandpaper.

Apply coat of BGC Exterior & Wet Area Top Coat along joints and over fasteners, smoothing out to approximately 80mm beyond base coat and allow to dry. Apply final coat to fasteners and allow to dry.

#### **Internal Corners**

Internal corners should be treated with BGC Exterior & Wet Area Base Coat in a 3 coat process to a total width extending not less than 100mm either side of the corner.

#### **External Corners**

External corners should be treated with BGC Exterior & Wet Area Base Coat in a 2 coat process to a total width extending not less than 250mm either side of the corner

Not to be used under tiled areas.

**Note /** This product is to be used as a Topping (final coat) over BGC Exterior & Wet Area Basecoat.



