



GTEK™ Ceiling

GTEK™ Ceiling back blocking
Bond back block to ceiling sheets with GTEK™ Back Blocking Cement (apply using notched spreader)

Position joint on centreline between ceiling joist or stud offset 50mm max.

Install temporary batten and packer to produce 3mm depression at joint. Leave in place for 24 hours min. after bonding the back block



Profile Wall & Ceiling
Detail Back Blocking 1

Date Nov 2015
Scale 1:2