



- Timber Framing
- GTEK™ Wet Area
- Liquid Membrane
- Wall tiling to builders specification
- Masking Tape
- Perimeter Flashing
- Foam plastic rod or flexible sealant used as essential bond breaker. Use tape to hold rod in place.
- Mortar Bed
- BGC Compressed fibre cement sheeting



Profile Wet Area  
Detail Insitu Shower Base

Date Nov 2015  
Scale 1:2